

# FAR Ultrasonic Wind Sensor



## Products description and application

FAR wind speed sensor is a maintenance free ultrasonic sensor. Product has no moving parts and has fast dynamic response, which is suitable for gust measurement. Built-in high efficiency heating device, ensure product normal operation in harsh cold environment. Designed for wind monitoring and wind resource assessment in the fields of engineering machinery, port machinery, factories and mines, wind power, environment protection, high way and railway.

## Features

- Adopt time difference measurement principle, strong capacity of environmental interference resistant
- Adopt high efficiency filtering algorithm, special compensation technology design for rain, fog weathers
- Various signal output for option
- Multistage lightning and surge protection design
- Power interface and signal interface full insulation design
- Stainless steel body, corrosion resistant and high strength

## General Specifications

Electrical		Mechanical	
Rated voltage	DC24V $\pm$ 20%	Material	Stainless steel
Operating current	100mA (DC24V)	Humidity	0%~100%RH
<sup>1</sup> Heating power	120W	Operating temperature	Ta-40°C ~ +70°C
Lightning surge	IEC61000-4-5 6kV /3kA	IP Rate	IEC60529 IP66
Electrostatic discharge	IEC61000-4-2 air discharge 15kV	Wiring	Aviation socket
	IEC61000-4-2 contact discharge 8kV	Color	Metallic
Signal output	4~20mA/0~20mA RS485	Weight	2.5 kg
Meteorological			
<sup>2</sup> Wind speed range	0~50m/s	Wind direction range	0°~360°
Accuracy wind speed	$\pm$ 0.2m/s (<10m/s) $\pm$ 2% (10m/s~60m/s)	Accuracy wind direction	$\pm$ 2°
Resolution wind speed	0.1m/s	Resolution wind direction	1°
Anti-wind level	>70m/s		

1. The heating function is turned off under default state. If you need the heating function, please refer to the communication protocol 1.5. If the heating function is turned on, when the temperature of the transducer cover drops below + 15 ° C, heating will be started; when the temperature of the cover reaches + 25 ° C, Stop heating.
2. This is the default state and can be customized.

# FAR Ultrasonic Wind Sensor



## Mounting dimensions

Unit: mm



The standard mounting type of FAR ultrasonic wind sensor is tube installation ( $\phi 50\text{mm}$ ), and have G3/4 male adapter for choice. G3/4 male adapter suit to board mounting (hole dimension is  $\phi 27\text{-}\phi 30\text{mm}$ ).

### Installation method:

1. Secure the  $\phi 50\text{mm}$  outer diameter tube or secure the G3/4 male adapter.
2. Insert the aviation plug of the cable from the  $\phi 50\text{mm}$  tube or G3/4 male adapter and insert into the aviation socket at the bottom of the sensor and lock it.
3. Put the sensor into the top of the installation tube and fix 4 M8 screws.


### Point to North:

To show the correct wind direction, the ultrasonic wind sensor must point to true north. The arm with red mark points to the north direction. Please align the arm with red mark to the geomagnetic pole (it can be checked by the north pointer).

**Note:** The magnetic north and the geographic north are not exactly the same, so the error in the position of the when correcting it.

Error related to the location, and its maximum error could be more than  $15^\circ$  (such as the northeast of China). In the east China area, the error is negligible ( $< 3^\circ$ ). More detailed information about this section is available on the Internet.


The FAR ultrasonic wind sensor is a precision instrument, please be handled with care.



## Wiring diagram

Pin assignment half duplex/analog interface:

- |   |                                   |        |
|---|-----------------------------------|--------|
| 1 | Wind speed Analog interface +     | pink   |
| 2 | RS485 Serial interface B-         | yellow |
| 3 | Wind direction Analog interface + | grey   |
| 4 | RS485 Serial interface A+         | green  |
| 5 | Analog ground                     | blue   |
| 6 | Supply voltage -                  | white  |
| 7 | Supply voltage +                  | brown  |



View of the aviation plug at the bottom of the sensor

### Caution :

1. Ensure cable connection is correct before power on.
2. Cable shield layer and housing must be reliably grounded.

## Protocol



Modbus protocol (Baud rate: 9600bit/s(factory setting), 8bit data, no parity check, one stop bit.)

Factory setting baud rate: 9600bit/s

Factory setting wind sensor address: 01H

## 1 Protocol description (default address: 01H)

### 1.1 Query wind speed data (coil address:122-123)

#### 1.1.1 Data definition

Command (Hexadecimal): 01 03 00 7A 00 01 A5 D3

Response(Hexadecimal): 01 03 02 00 44 B8 77

#### 1.1.2 Byte definition

Command character

The first byte 01H is the device address

The second byte 03H is the function code

The 3rd and 4th bytes 00H and 7AH are the coil start addresses

The 5th and 6th bytes 00H and 01H are the number of coils

The 7th and 8th bytes 60H and F0H are the upper and lower bits of the first 6 bytes

of the CRC check code

Response character

The first byte 01H is the device address

The second byte 03H is the function code

The third byte 02H is the number of returned bytes

The 4th and 5th bytes 00H and 44H are the hundred times of the wind speed, for

example, 00H, 44H or 68, indicating the wind speed is 0.68 m/s

The sixth and seventh bytes 60H and F0H are the upper and lower bits of the first

five bytes of the CRC check code

### 1.2 Query wind speed data (coil address:122-123)

#### 1.2.1 Data definition

Command (Hexadecimal): 01 03 00 7B 00 01 F4 13

Response(Hexadecimal): 01 03 02 68 98 96 2E

#### 1.2.2 Byte definition

Command character

The first byte 01H is the device address

The second byte 03H is the function code

The 3rd and 4th bytes 00H and 7BH are the coil start addresses

The 5th and 6th bytes 00H and 01H are the number of coils

The 7th and 8th bytes F4H and 13H are the upper and lower bits of the first 6 bytes

of the CRC check code

Response character

The first byte 01H is the device address

The second byte 03H is the function code

The third byte 02H is the number of returned bytes

The 4th and 5th bytes 68H, 98H are the hundred times of the wind speed, for

example 68H, 98H or 26776, indicating the wind direction is 267.76 °

The sixth and seventh bytes 96H and 2EH are the upper and lower bits of the first

five bytes of the CRC check code

### 1.3 Modify address command

#### 1.3.1 Data definition

Command (Hexadecimal): 01 10 00 00 00 02 04 00 00 00 03 B3 AE

Response(Hexadecimal): 01 10 00 00 00 02 41 C8

#### 1.3.2 Byte definition

Command character

The first byte 01H is the device address

The second byte 10H is the function code

The 3rd and 4th bytes 00H and 00H are the coil start addresses

The 5th and 6th bytes 00H and 02H are the number of coils

The 7th byte 04H is the number of bytes

The 8th, 9th, 10th, and 11th bytes of 00H, 00H, 00H, and 03H are data (value range

1-32)

The 12th and 13th bytes 60H and F0H are the upper and lower bits of the first 11

bytes of the CRC check code

Response character

The first byte 01H is the device address

The second byte 10H is the function code

The 3rd, 4th, 5th and 6th bytes 00H, 00H, 00H and 02H are the number of returned

bytes

The 7th and 8th bytes 41H and C8H are the upper and lower bits of the first 6 bytes

of the CRC check code

### 1.4 Automatically send wind speed/wind direction command (coil address: 101-102, default status is off)

#### 1.4.1 Data definition

Command (Hexadecimal): 01 10 00 20 00 01 02 00 01 60 F0

Response(Hexadecimal): 01 10 00 20 00 01 00 03

#### 1.4.2 Byte definition

Command character

The first byte 01H is the device address

The second byte 10H is the function code

The 3rd and 4th bytes 00H and 20H are the coil start addresses

The 5th and 6th bytes 00H and 01H are the number of coils

The 7th byte 02H is the number of bytes

The 8th and 9th bytes 00H and 01H are data (value range 0-1, 0 is not automatically

sent, non-zero is automatically sent)

The 10th and 11th bytes 60H and F0H are the upper and lower bits of the first 9

bytes of the CRC check code

Response character

The first byte 01H is the device address

The second byte 10H is the function code

The 3rd and 4th bytes 00H and 20H are the coil start addresses

The 5th and 6th bytes 00 and 01H are the number of returned bytes

The 7th and 8th bytes 00H and 03H are the upper and lower bits of the first 6 bytes

of the CRC check code

### 1.5 Switch heating function command (coil address 101-102, default status is off)

#### 1.5.1 Data definition

Command (Hexadecimal): 01 10 00 65 00 01 02 00 01 6E 65

Response(Hexadecimal): 01 10 00 65 00 01 11 D6

#### 1.5.2 Byte definition

Command character

The first byte 01H is the device address

The second byte 10H is the function code

The 3rd and 4th bytes 00H and 65H are the coil start addresses

The 4th and 5th bytes 00H and 01H are the number of coils

The sixth byte 02H is the number of bytes

The 7th and 8th bytes 00H and 01H are data (value range 0-100 (decimal), 0 is no

heating, 1 is heating power ( 1% of total power), and so on.100 is full power heating

The default is no heating

The 9th and 10th bytes 6EH and 65H are the upper and lower bits of the first 8 bytes

of the CRC check code

Response character

The first byte 01H is the device address

The second byte 10H is the function code

The 3rd and 4th bytes 00H and 65H are the coil start addresses

The 5th and 6th bytes 00H and 01H are the return values

The 7th and 8th bytes 11H and D6H are the upper and lower bits of the first 6 bytes

of the CRC check code

### 1.6 Broadcast Modify Device Address is 01H Command

#### 1.6.1 Data definition

Host computer command: 00 10 00 00 00 02 04 00 00 00 01 36 93

#### 1.6.2 Byte Definition:

Command character

The first byte 00H is the broadcast address

The second byte 10H is the function code

The 3rd and 4th bytes 00H and 00H are the coil start addresses

The 5th and 6th bytes 00H and 02H are the number of coils

The 7th byte 04H is the number of bytes

The 8th, 9th, 10th, and 11th bytes of 00H, 00H, 00H, and 01H are data (value range

1-32)

The 12th and 13th bytes 36H and 93H are the upper and lower bits of the first 11

bytes of the CRC check code

## 2 Supplementary

2.1 Please mark as soon as possible after modifying the address; up to 32 slaves can be hanged on a

single bus.

2.2 CRC check using ANSI CRC16: The polynomial is X16+X15+X2+1.

2.3 The interval between frames and frames is not less than 500ms.

2.4 Broadcast commands are executed by all slaves, but do not reply to data.

# FAR Ultrasonic Wind Sensor



Automatically send wind speed/wind direction command (Baud rate: 9600bit/s(factory setting), 8bit data, no parity check, one stop bit)

1. Data definition: auto-output a frame per 1s, total 7 bytes.

0xAA/0xBB	0x04	0xXX	0xXX	0xZZ	0xZZ	checksum
-----------	------	------	------	------	------	----------

Byte definition: AA is synchronous-head, 0x04 is message length, next two bytes combine a word 0xXX which indicate wind speed, and next two bytes combine a word 0xZZ which indicate wind direction. Checksum= 0xXX+0xXX+0xZZ+0xZZ, indicate checksum.

**If the frame header is 0xBB that means the sensor is faulty.**


2.For example: 0xAA 0x04 0x01 0x6A 0x01 0x2C 0x98

Wind speed is 0x016A = 36.2m/s


Wind direction is 0x012C =300°

## Output characteristic curve

Current output characteristic curve of wind speed



Current output characteristic curve of wind direction



## How to Order

P/N	Model	Rated voltage	Signal output	Heating Function	Mount
1000409-001	FAR	DC24V±20%	4-20mA current, 0-50m/s, 0-360° RS485	Yes (Heating power ≤120W)	Ø50 mast tube mount, 7-pin aviation socket
1000409-002	FAR	DC24V±20%	4-20mA current, 0-60m/s, 0-360° RS485	Yes (Heating power ≤120W)	Ø50 mast tube mount, 7-pin aviation socket

## Annex

Installation diagram	Product name	Description
	Safety wire	1.Tighten the M8 eyebolts 2.The installation of safety wire as the picture shown
	Anti-bird tip	1.Apply thread fastening agent to the anti-bird tip thread; 2.Screw the anti-bird tip into the upper threaded hole of the ultrasonic

Thanks for choosing our products, NANHUA Electronics is the professional brand of signal transmission and high quality industrial lighting which is trusted and loved by global users from various industries. Read and understand these instructions completely and carefully. Wrong installation and operation may lead to fires, electric shock, and others. Due to our continued efforts to improve our products, product specifications are subject to change without notice.

©NANHUA Electronics Co., Ltd. All rights reserved.www.nanhua.com